



## Winterizing a MistAway Gen 1.2 Drum Unit

- 1. Flush pump (and agitation valve if equipped) with clean water:**
  - a. Fill 5 gallon bucket with fresh water and position next to unit.
  - b. Remove drum lid (with mounted assembly) from drum and, with a tie wrap, secure float switch bulb to pump intake line in up/floating position.
  - c. Position lid assembly on top of 5 gallon bucket so that pump intake line and float (and agitation line, if equipped) are submerged.
  - d. Reset level in tank (MAINTENANCE Menu, LEVEL, press SELECT knob for 5 seconds, use knob to establish positive tank level, press SELECT knob.)
  - e. Activate an extended manual mist. The mist cycle will flush the pump and nozzle circuit. If zone kit, run mists on both zones to flush both nozzle circuits.
  - f. Remove intake line (and agitation line, if equipped) from bucket, disconnect nozzle circuit line, and activate a dry (i.e., suction line not in any fluid) manual mist to clear water from pump.
  - g. Reposition drum lid and assembly back on drum.
- 2. Unplug unit and wrap power cord around assembly.**
- 3. Replace waterproof cover.**
- 4. Purge fluid remaining in nozzle circuit with compressed air.**
  - a. Remove the tip from the last nozzle on the end of each run.
  - b. Use portable air compressor with adapter (MistAway Part # 20052) to purge fluid from nozzle circuit.